



NIEUWKOOP

USER MANUAL



EP6000

CALIBRATION STATION



TO MEASURE  TO KNOW



- Unpack the box and make sure that all parts have been supplied:
 - Plateau with four holes
 - 4 tubes (EC4.00, pH4.01, pH6.86 en Demi-water)
 - 4 pouches with solutions (EC4.00, pH4.01, pH6.86 en Demi-water)



- Place the tubes in the holes of the plateau.
- Place the manual with the calibration procedure in the back of the plateau.
- The supplied pouches with solutions are for single use. After use, please take new pouches or bottles with the same calibration liquid to fill the tubes again.
- The tubes can be emptied after use and rinsed with demi- or distilled water. The solutions do not contain any chemical parts or harmful substances.
- Make sure that you always use fresh solutions.
- The calibration station is ready for use!



TO MEASURE  TO KNOW

Nieuwkoop BV

Aalsmeerderweg 249 -S

1432 CM AALSMEER

0297 325836

info@nieuwkoopbv.nl

www.meten.nl



NIEUWKOOP