CONNECTION EC-SENSOR EC5105 ON CONTROLLER EC3001

CABLE CONNECTION

EC-sensor with temperature compensation:

Brown/Red	10
Orange	13
Yellow	14
Transparent	Not connected
Green	15
Black/Transparent	11
Black Shield	15

POWER SUPPLY

10/30 Volt DC :2 (-) and 3 (+) TAKE CARE!!!

SET-UP REFERENCE TEMPERATURE

The reference temperature has a factory value of 20°C. If you use the calibration liquid of, for example, Nieuwkoop BV (which has a reference temperature of 25°C), please set the reference temperature to 25°C as follows:

ZERO
MODE Press this key 2 times, display will show Set-up
ENT Press this key 6 times, display will show Temp.Ref, followed by 20°C
or Press to select the value (25°C)
ENT Press to confirm, (UPDATE will appear)
MODE Press 4 times to go back to the main menu

CALIBRATION

ZERO:

When the sensor is not immersed into a solution, the controller should show 0. If the controller does not show 0, we can recalibrate it to 0 as follows. MAKE SURE THAT THE SENSOR IS CLEAN AND DRY!!!!

ZERO

MODE Press this key for 8 seconds, display will show Zero Cal, followed by the actual value

ENT Press to confirm, display will show Zeroing 0-5 and is ready as soon as UPDATE appears



SPAN:

After the connection of the controller, we need to calibrate with a buffer solution. Please check if the reference temperature is 20°C or 25°C!!

- 1) Immerse sensor into the calibration liquid and wait for ± 30 seconds (because of automatic temperature compensation).
- 2) When the value is stable, the controller can be adjusted according to the value of the calibration liquid as follows:

	SENS	
ſ	>	

SENS

Press this key for 8 seconds, display will show 5ens Cal, followed by the actual value. Wait for the stabilization of the value

▲ or ♥ Press to select the value, display will show value (XX•XX•MS)

ENT Press to confirm, display will show Wait and is ready when UPDATE appears.

ADJUSTING RANGE

 ZERO

 MODE

 Press this key 3 times, display will show

 ENT

 Press this key 3 times, display will show

 SENS

 ^

 of

 V

 Press to select the value

 ENT

 Press to confirm, display will show

 UPDATE

 ZERO

 MODE

 Press 3 times to return to the main menu

COMPLETE USER MANUAL

Scan the QR code for the complete user manual.



