


Quick manual – EC1200 & EC1210



NIEUWKOOP

Measuring



1. Place the EC sensor in the to be measured liquid.
2. Press the **MODE** button to turn on the instrument. The date of the last calibration, if set, is displayed first. Then the current EC value of the liquid/soil appears on the display. Wait until the value is stable and read it.

Extra notes EC1210 model for direct measurements in soil:

1. Always insert the sensor straight into the soil in a smooth movement and measure at the same depth, otherwise differences in measurements may occur.
2. The EC1210 model can measure in soil as well as in water.
3. By measuring in the indicated manner, a line of EC measurements is created on which the fertilization application can be anticipated.
4. In case of doubt, it is recommended to prepare a soil sample in our ABC sample cup. This can be done by means of the 1:2 or 1:5 mixing ratio.

Calibration



When the EC sensor is clean and not in a liquid or soil, the EC meter should read 0 (or close to it). If this is not the case, a 0 calibration must be performed first. See the complete manual on our website www.nieuwkoopbv.nl.

1. Place the EC sensor in the Nieuwkoop EC 4.00 liquid.
2. Press the **SET UP** key for approximately 3 seconds and **SENS CAL** will appear on the display, followed by an EC value.
3. **Wait until the value is stable!**
4. Short press the **SET UP** button, the default calibration value **4.00** will appear on the display.
5. Press the **SET UP** button for approximately 3 seconds to confirm this.
6. **LAST CAL** will appear in the display followed by **xx/xx/xx** (this is the date of the last calibration). With the **INCR** button the number can be changed and with the **SET UP** button the position is selected. After setting, press the **SET UP** button for approximately 3 seconds to confirm the date. **UPDATE** appears on the display.

Extra note EC1210 model for the calibration:

Calibrating the instrument and the penetration sensor is the same as for the measurement in water model, the EC1200. Please note that the sensor needs to have a distance of approximately 1 centimeter from the wall of the bottle / container in which the calibration is done. If not, it may affect the measurement/calibration.



Calibration video EC1200

Calibration video EC1210



Activate your warranty!
www.nieuwkoopbv.nl/en/warranty



Quick manual – PH1200 & PH1210



Measuring



1. Remove the storage bottle and place the pH sensor in the to be measured liquid or soil.
2. Press the **MODE** button to turn on the instrument. The date of the last calibration, if set, is displayed first. Then the current pH value of the liquid appears on the display. Wait until the value is stable and read it.

Calibration



Press the MODE button to turn on the instrument.

1. Remove the storage bottle and place the pH sensor in the Nieuwkoop pH 6.86 liquid.
2. Press the **LOG** button for approximately 3 seconds and **ZERO CAL** will appear on the display, followed by a pH value.
3. **Wait until the value is stable!**
4. Short press the **SET UP** button, the default calibration value **6.88** will appear on the display.
5. Press the **SET UP** button for approximately 3 seconds to confirm this.
6. **LAST CAL** will appear in the display followed by **xx/xx/xx** (this is the date of the last calibration). With the **INCR** button the number can be changed and with the **SET UP** button the position is selected. After setting, press the **SET UP** button for approximately 3 seconds to confirm the date. **UPDATE** appears on the display.
7. **Rinse the sensor well and then dry it without touching the glass part too much.**
8. Place the pH sensor in the Nieuwkoop pH 4.01 liquid.
9. Press the **SET UP** button for approximately 3 seconds and **SENS CAL** will appear on the display, followed by a pH value.
10. **Wait until the value is stable!**
11. Short press the **SET UP** button, the default calibration value **4.00** will appear on the display.
12. Press the **SET UP** button for approximately 3 seconds to confirm this.
13. **LAST CAL** will appear in the display followed by **xx/xx/xx** (this is the date of the last calibration). With the **INCR** button the number can be changed and with the **SET UP** button the position is selected. After setting, press the **SET UP** button for approximately 3 seconds to confirm the date. **UPDATE** appears on the display.



**Calibration video
PH1200 & PH1210**

TO MEASURE  TO KNOW

Activate your warranty!
www.nieuwkoopbv.nl/en/warranty

